

## RIVKLE® Tool support

Practical support for the RIVKLE® setting tool B2007.

Technical information can be found on the last page.



Article number	For tool type
23616600308	B2007

All technical data refer to the measure mm






Head diameter  
Overall length  
Thread size




**Grip range**

Defines the range of total thickness of the customers part (even if it consists of more than one layer)



**Hole geometry**

If round → diameter  
If hexagonal → width across flats



**Head projection after setting**

Variable according to the application (setting load, material substrate, etc.)


**Blind side projection after installation**

Defines the clearance needed on the blind side (cannot be used for quality control)


**Setting stroke**

Difference of total length before and after installation

**RIVKLE® Nut**



**RIVKLE® Stud**



- RIVKLE®
- Mandrel\*
- Customers part
- Anvil\*
- Counter nut
- Setting tool

\*in accordance to chosen RIVKLE®\*

All technical data refer to the measure mm

